

Final Rega Planet & Jupiter CD Remote Control Data. 07/06/2005

Function	Code	Hex	Comments
Existing Functions:			
Shuffle	00000000	00	
Repeat	00000001	01	
Time	00000010	02	
Program	00000011	03	
Check	00000111	07	
Clear	00001000	08	
1	00001001	09	
FR	00001010	0A	
Pause	00001011	0B	
4	00001101	0D	
Previous	00001110	0E	
Stop	00001111	0F	
7	00010001	11	
0	00010010	12	
Play	00010011	13	
8	00010101	15	
>10	00010110	16	
9	00010111	17	
Display	00011000	18	
5	00011001	19	
Next	00011010	1A	
6	00011011	1B	
2	00011101	1D	
FF	00011110	1E	
3	00011111	1F	
New Functions:			
Text (MP3)	00100000	20	Toggles through MP3/WMA Text.
+10 Tracks	00100001	21	
-10 Tracks	00100010	22	
Album Up	00100011	23	Up Album MP3/WMA
Album Down	00100100	24	Down Album MP3/WMA
>100	00100101	25	
Digital Input 1	00100110	26	future use – not used
Digital Input 2	00100111	27	future use – not used
Eject CD	00010000	10	future use – not used

Rega Planet & Jupiter CD Remote Control, Customer Code and System Type.

Customer Code (HEX)	System	Comments
916E	NEC	